1. Start out by oiling the entire machine. The machine has been properly greased before leaving the Mereen-Johnson assembly floor.

Do not regrease the motor bearings.

- 2. Set up a lubrication schedule. See example at the end of the section
- 3. See the machine placard for specific location of oil cups and grease fittings.

Grease every 400 hours of running time. *Do not over grease*. Excessive greasing will cause the bearings to run *hot*.

Use only a premium grade Hi-Speed Extreme Pressure (EP) ball bearing grease. Refer to the following pages for recommendations.

Wipe off all grease fittings before and after greasing.

It is recommended that these greases or their equivalents be used on the Mereen-Johnson Machine Company Equipment.

Gopher Oil Company	Molylub 126-EP, #1 or #2
Continental Oil Company	Conoco Superlub NLGI #2
Shell Oil Company	Cyprina #3
Socony Vacuum Oil Company.	Mobilux #2
Standard Oil of California	Calol
The Texas Company	Unitemp
The Texas Company	Hitetemp
The Texas Company	Regal Starfak AFB #2
Sunoco	Sunaplex 992 EP

Preventative Maintenance

Lubrication





Greasing

General Recommendations

Grease

Lubrication (Con't.)





ITEM.	DESCRIPTION	FREQUENCY
1	HOLD DOWN PIVOT BEARINGS	YEARLY
2	GEARBOX, DRIVE ROLLS	LUBE CHANGE YEARLY
3	GUIDE FENCE BEARINGS	400 HOURS
4	GEARBOX, GUIDE FENCE	LUBE CHANGE YEARLY
5	JUMP PIVOT SHAFT BEARINGS	YEARLY
6	CHAIN DRIVE SHAFT BEARINGS	400 HOURS
7	GEARBOX, CHAIN DRIVE	LUBE CHANGE YEARLY